


Cable Connector Descriptions



A. Triax BNC Plug
(M/F) [2-lug]



B. Triax BNC Jack
(F/M) [2-lug]




C. Triax TNC Plug
(M/F)




D. Triax TNC Jack
(F/M)



E. Coax BNC Plug
(M/F) [2-lug]



F. Banana Plug




G. Coax BNC Jack
(F/M) [2-lug]



H. Banana Jack



I. Triax BNC Plug
(M/F) [3-lug]



J. Triax LEMO Plug
(F/M)



K. Triax TNC Plug
(F/F)



L. Triax TNC Jack
(M/M)




M. Coax SHV Plug
(F/F) [2-lug]



N. Coax MHV Plug
(M/F) [2-lug]



O. Triax Type M
(M/M)



P. Triax Type M
(F/F)

Naming convention: Connector Type (center pin gender / outer housing gender)

NOTE: Letters are for reference only and are not actual part numbers.



Distributed by SeeDOS Ltd
For further information or a quotation please contact Colin Walters
at cwalters@seedos.com

